

# Machine Safeguarding Map

Equipment Name: Phone		Equipment #: Qwe	
Department: Sales	Created By: Scott	Approved by:	Date:

**NOTE: Ensure all safeguards are in-place, secured and functional before operating this machine**



## [C-1]

Chain: Verify it is latched in place. Chain is not broken or missing links.

---

## [SM-1]

Safety Mat: When machine is not in operation, step on mat and test that machine will not start until it is reset.

---

---

---