

# Machine Safeguarding Map

Equipment Name: Phone		Equipment #: Qwe	
Department: Sales	Created By: Scott	Approved by:	Date:



**NOTE: Ensure all safeguards are in-place, secured and functional before operating this machine**

<p>[C-1] [SM-1]</p> <hr/>		<p>Chain: Verify it is latched in place. Chain is not broken or missing links.</p> <p>Safety Mat: When machine is not in operation, step on mat and test that machine will not start until it is reset.</p> <hr/>
-------------------------------	--	---