

Machine Safeguarding Map

Equipment Name: Upcut Saw – V2

Equipment #: 1

Department: Roughend

Created By: Nick Steiner

Approved by: Luc Connor

Date: 03/07/2025

NOTE: Ensure all safeguards are in-place, secured and functional before operating this machine

Individual Guarding Descriptions & Requirements



[H-1]

Hard Guard: Yellow Pulley Guard – Attached to machine. All fasteners in place. Guard is secure and does not have sharp edges.



[H-1]

Hard Guard: Orange Blade Guard – Attached to machine. All fasteners in place. Guard is secure and does not have sharp edges.



[F-1]

Foot Control: Pedal is secured beneath the cover.